

iBox Nano

Mini printer résine.

Présentation du projet

Projet archivé

Il manque un auto-collant en téflon ([User Guide \(What is that tape on the bottom\)](#)) dans le fond de la cuve.

Impossible de garder le print sur le plateau montant. A tester selon le User Guide (What should I do if a print fails?):

- Make sure the build plate is down far enough before starting a print.
- Make sure the first few layers are over-exposed which increases the adhesion to the Build Plate. This is set in [Settings] as [First Layers : Over-Exposure Time and Count]
- You can also use a large Foundation to assure the adhesion favors the Build Plate. This can be found in [Settings] [Foundation...]. Foundation layers print before the model layers and can have a higher exposure time and drive current than the model to increase adhesion to the Build Plate]

Participants

Qui	Statut	Rôle
John	Mainteneur	Initiation du projet
Edwin	Participant	

Besoins

- Auto-collants Téflon : <http://www.amazon.com/CS-Hyde-Optically-Silicone-Adhesive/dp/B000REI90W>

Mis à jour 16 juin 2020 11:31:09